


Working Method AIRMOUNTING-MODULE

Single AIR-Mounting-Tool




Step 1: Close the module by hand



Step 2: Put the grommet in the module



Step 3: Press foot with and push the cable through the module and the grommet



Step 4: Is the cable on the correct position, stop pressing foot with and the module are opening



If you want to change the grommet position, you must adjust the cableholder at another position

